EN

User Manual
Amzdeal Energy Magnetic
Wireless Power Bank Super Slim 5*15kB
Magnetic coil installation image
The magnetic coil is installed on the back of the device in the middle of the double-sided tape.
Please stick the coil on the back of the phone and the protective case, paying proper alignment with the wireless charging area.

Using magnetic wireless charging on new MagSafe devices
Attach the magnetic ring to the back of your iPhone 13, and other mobile phones that support wireless charging. Align the ring with the MagSafe magnets and it will magnetically fix adding magnetic rings. Then, place your device on the charger so that the magnet on the outside of the protective

Using magnetic wireless charging on new MagSafe devices
Attach the magnetic ring to the back of your iPhone 13, and other mobile phones that support wireless charging. Align the ring with the MagSafe magnets and it will magnetically fix adding magnetic rings. Then, place your device on the charger so that the magnet on the outside of the protective

Magnetic coil installation image
The magnetic coil is installed on the back of the device in the middle of the double-sided tape.
Please stick the coil on the back of the phone and the protective case, paying proper alignment with the wireless charging area.

Using magnetic wireless charging on new MagSafe devices
Attach the magnetic ring to the back of your iPhone 13, and other mobile phones that support wireless charging. Align the ring with the MagSafe magnets and it will magnetically fix adding magnetic rings. Then, place your device on the charger so that the magnet on the outside of the protective

LED display indicators
Fast charge indicator
Full charge indicator
Battery indicator
Battery indicator
Charging indicator
The power display

Output & fast function overview
Supports Type-C to Type-C fast charging cable, Type-C to USB fast charging cable, Type-C to MagSafe magnetic fast charging cable, and other wireless charging products.

Usage instructions
1. Power On/Off
Press the button to turn on the device. Press and hold the button for 3 seconds to turn off the device.
2. Simultaneous charging & discharging
Connect the device to a power source and other devices charging simultaneously.

Product overview
1. Type-C fast charging/data charging area
2. Battery level indicator
3. Type-C port
4. Charge input indicator

Technical data
Model: Super Slim 5*15kB
Capacity: 5,000 mAh/18.5 Wh
Battery energy: 18.5 Wh
Input: Type-C PD 3.0 5 V, 3 A/ 9 V, 2.22 A; Type-C PD 3.0 5 V, 3 A/ 9 V, 2.22 A; Wireless input: 5 V/ 2 A; 7.5 W / 9 V/ 2 A; 10 W / 12 V/ 1.5 A; 15 W
Wireless output: 5 V/ 1 A; 7.5 W / 9 V/ 1 A; 10 W / 12 V/ 1 A; 15 W
Product size: 106 x 69 x 13.5 mm
Product weight: 180 g

Package content
Apple MagSafe compatible wireless charger
Apple Watch charger
Type-C to Type-C cable
User manual

Troubleshooting
1. Power bank cannot be charged
Please check if the power bank is connected to a power source.
2. Power bank cannot be discharged
Please check if the power bank is turned on.
3. Slow charging
Please check if the power bank is connected to a power source.
4. Wireless charging not working
Please check if the power bank is turned on.
5. Wireless charging not working
Please check if the power bank is turned on.

Technische Daten
Modell: Super Slim 5*15kB
Kapazität: 5.000 mAh/18,5 Wh
Batterieenergie: 18,5 Wh
Eingang: Type-C PD 3.0 5 V, 3 A/ 9 V, 2,22 A; Type-C PD 3.0 5 V, 3 A/ 9 V, 2,22 A; Wireless input: 5 V/ 2 A; 7,5 W / 9 V/ 2 A; 10 W / 12 V/ 1,5 A; 15 W
Wireless output: 5 V/ 1 A; 7,5 W / 9 V/ 1 A; 10 W / 12 V/ 1 A; 15 W
Produktgröße: 106 x 69 x 13,5 mm
Produktgewicht: 180 g

Lieferumfang
Apple MagSafe kompatibles kabelloses Ladegerät
Apple Watch Ladegerät
Type-C zu Type-C Kabel
Bedienungsanleitung

Fehlerbehebung
1. Powerbank kann nicht aufgeladen werden
Bitte überprüfen Sie, ob die Powerbank mit einer Stromquelle verbunden ist.
2. Powerbank kann nicht entladen werden
Bitte überprüfen Sie, ob die Powerbank eingeschaltet ist.
3. Langsames Laden
Bitte überprüfen Sie, ob die Powerbank mit einer Stromquelle verbunden ist.
4. Kabelloses Laden funktioniert nicht
Bitte überprüfen Sie, ob die Powerbank eingeschaltet ist.
5. Kabelloses Laden funktioniert nicht
Bitte überprüfen Sie, ob die Powerbank eingeschaltet ist.

Produktübersicht
1. Ladebereich für Type-C Schnellladung/Datenübertragung
2. Batterieanzeige
3. Type-C Anschluss
4. Ladeeingangsanzeige

Bedienungsanleitung
1. Ein-/Ausschalten
Drücken Sie die Taste, um das Gerät einzuschalten. Halten Sie die Taste gedrückt, um das Gerät auszuschalten.
2. Gleichzeitiges Laden & Entladen
Verbinden Sie das Gerät mit einer Stromquelle und anderen Geräten, um sie gleichzeitig aufzuladen.

Übersicht der Anzeigen
Schnellladeanzeige
Vollladeanzeige
Batterieanzeige
Batterieanzeige
Ladeanzeige
Die Leistungsanzeige

Übersicht über Eingänge/Ausgänge & schnelle Funktionen
Unterstützt Type-C zu Type-C Schnellladekabel, Type-C zu USB Schnellladekabel, Kabellose Ladetechnologie, 7.5 W / 7.5 W / 10 W / 15 W Apple MagSafe Magnetische Schnellladekabel, kabellose Ladegeräte anderer Hersteller.

Anleitung zur Verwendung
1. Ein-/Ausschalten
Drücken Sie die Taste, um das Gerät einzuschalten. Halten Sie die Taste 3 Sekunden lang gedrückt, um das Gerät auszuschalten.
2. Gleichzeitiges Laden & Entladen
Verbinden Sie das Gerät mit einer Stromquelle und anderen Geräten, um sie gleichzeitig aufzuladen.

Produktübersicht
1. Ladebereich für Type-C Schnellladung/Datenübertragung
2. Batterieanzeige
3. Type-C Anschluss
4. Ladeeingangsanzeige

Technische Daten
Modell: Super Slim 5*15kB
Kapazität: 5.000 mAh/18,5 Wh
Batterieenergie: 18,5 Wh
Eingang: Type-C PD 3.0 5 V, 3 A/ 9 V, 2,22 A; Type-C PD 3.0 5 V, 3 A/ 9 V, 2,22 A; Wireless input: 5 V/ 2 A; 7,5 W / 9 V/ 2 A; 10 W / 12 V/ 1,5 A; 15 W
Wireless output: 5 V/ 1 A; 7,5 W / 9 V/ 1 A; 10 W / 12 V/ 1 A; 15 W
Produktgröße: 106 x 69 x 13,5 mm
Produktgewicht: 180 g

Lieferumfang
Apple MagSafe kompatibles kabelloses Ladegerät
Apple Watch Ladegerät
Type-C zu Type-C Kabel
Bedienungsanleitung

Fehlerbehebung
1. Powerbank kann nicht aufgeladen werden
Bitte überprüfen Sie, ob die Powerbank mit einer Stromquelle verbunden ist.
2. Powerbank kann nicht entladen werden
Bitte überprüfen Sie, ob die Powerbank eingeschaltet ist.
3. Langsames Laden
Bitte überprüfen Sie, ob die Powerbank mit einer Stromquelle verbunden ist.
4. Kabelloses Laden funktioniert nicht
Bitte überprüfen Sie, ob die Powerbank eingeschaltet ist.
5. Kabelloses Laden funktioniert nicht
Bitte überprüfen Sie, ob die Powerbank eingeschaltet ist