

Power Bank

User Manual



• Specification

Model: Slim DG-P8
Item: Magnetic Power Bank (MagSafe-compatible)
Dimension: 97 × 64 × 15.9 mm
Weight: 116 g
Material: ABS + silicone
Battery type: Lithium polymer battery
Capacity: 5,000 mAh (3.85 V) / 19.25 Wh
Input (USB-C): PD 18 W (5 V=3 A, 9 V=2 A)
Output (USB-C): PD 20 W (5 V=3 A, 9 V=2.22 A, 12 V=1.67 A)
Wireless Output (Magnetic): 5 W / 7.5 W / 10 W / 15 W (Max)
Total Output: 15 W Max
Operating Temperature: -10°C to 40°C
Charging Time: Approx. 3–5 hours
Execution Standard: GB/T 35590-2017

• Special Notice

1. When charging this product, use a charger produced and certified by a reputable manufacturer. Charging time may vary depending on the charger used.
2. If the device cannot be charged, please check whether the cable is properly connected and whether the charging interface is compatible.
3. Due to energy conversion efficiency, the power bank's rated capacity does not equal its actual output capacity.
4. This product supports magnetic wireless charging compatible with MagSafe-enabled devices. For optimal performance, ensure the

device is properly aligned with the magnetic surface.
5. This product is compatible with most smartphones, but some individual models may not be supported.

• Safety Information

1. The power bank uses high-quality lithium polymer cells. Please read the following precautions carefully before use. Failure to follow these instructions may result in product damage or injury.
2. Do not throw, drop, disassemble, or tamper with this product.
3. Do not place the product in fire or water.
4. Do not expose the product to excessively high temperatures (e.g., inside a vehicle in summer).
5. Do not expose the product to direct sunlight for prolonged periods.
6. Use only certified power adapters that meet applicable safety standards.
7. Place the product on a stable surface during use. If used in contact with the human body, limit contact time.
8. Do not use the product after immersion in water.
9. Improper battery replacement may cause an explosion risk. Battery replacement may only be performed by qualified service personnel. Do not crush, puncture, disassemble, or dispose of the battery in fire. Do not use the product if severe swelling occurs.

• After-sales Service and Support

1. The warranty period begins from the date of purchase as indicated on the official proof of purchase (invoice or valid receipt). The main unit (excluding accessories) is eligible for replacement within 1 month and is covered by a 1-year warranty.
2. Please retain the purchase receipt and present it when requesting service. If proof of purchase is unavailable, the warranty period will be calculated from the production date indicated on the product label.
3. If the product malfunctions during normal use during the warranty period due to a manufacturing defect, it will be repaired or replaced free of charge after inspection.
4. The company is not responsible for any indirect or incidental damages.
5. The warranty does not cover:
 - a. Damage caused by misuse or human factors;
 - b. Damage resulting from improper installation or failure to follow the instruction manual;
 - c. Damage caused by natural disasters or force majeure;
 - d. Damage caused by unauthorized repair, modification, or disassembly;
 - e. Expired warranty period;
 - f. Product accessories.

Producer / Produzent / Producent:
Partner Tele.com Sp. z o.o. Sp. k., ul. Sołtyśowska 22,
31-589 Kraków, Polska, contact.safety@partnertele.com,
info@partnertele.com

Powerbank

Instrukcja obsługi



• Specyfikacja

Model: Slim DG-P8
Produkt: Magnetyczny power bank (kompatybilny z MagSafe)
Wymiary: 97 × 64 × 15,9 mm
Waga: 116 g
Materiał: ABS + silikon
Typ baterii: Akumulator litowo-polimerowy
Pojemność: 5 000 mAh (3,85 V) / 19,25 Wh
Wejście (USB-C): PD 18 W (5 V=3 A, 9 V=2 A)
Wyjście (USB-C): PD 20 W (5 V=3 A, 9 V=2,22 A, 12 V=1,67 A)
Wyjście bezprzewodowe (magnetyczne): 5 W / 7,5 W / 10 W / 15 W (maks.)
Łączna moc wyjściowa: 15 W maks.
Temperatura pracy: -10°C do 40°C
Czas ładowania: Około 3–5 godzin
Norma wykonania: GB/T 35590-2017

• Uwagi specjalne

1. Podczas ładowania produktu używaj ładowarki wyprodukowanej i certyfikowanej przez renomowanego producenta. Czas ładowania może się różnić w zależności od użytej ładowarki.
2. Jeśli urządzenie nie ładuje się, sprawdź, czy kabel jest prawidłowo podłączony oraz czy interfejs ładowania jest kompatybilny.
3. Ze względu na sprawność konwersji energii, znamionowa pojemność power banku nie jest równa jego rzeczywistej pojemności wyjściowej.
4. Produkt obsługuje magnetyczne ładowanie bezprzewodowe kompatybilne z urządzeniami

wyposażonymi w MagSafe. Dla optymalnej wydajności upewnij się, że urządzenie jest prawidłowo wyrównane względem powierzchni magnetycznej.
5. Produkt jest kompatybilny z większością smartfonów, jednak niektóre modele mogą nie być obsługiwane.

• Informacje dotyczące bezpieczeństwa

1. Power bank wykorzystuje wysokiej jakości ogniwa litowo-polimerowe. Przed użyciem należy dokładnie zapoznać się z poniższymi środkami ostrożności. Nieprzestrzeganie instrukcji może spowodować uszkodzenie produktu lub obrażenia.
2. Nie rzucaj, nie upuszczaj, nie rozbieraj ani nie modyfikuj produktu.
3. Nie umieszczaj produktu w ogniu ani w wodzie.
4. Nie wystawiaj produktu na działanie bardzo wysokich temperatur (np. wewnątrz pojazdu latem).
5. Nie wystawiaj produktu na bezpośrednie działanie promieni słonecznych przez dłuższy czas.
6. Używaj wyłącznie certyfikowanych zasilaczy spełniających obowiązujące normy bezpieczeństwa.
7. Podczas użytkowania umieść produkt na stabilnej powierzchni. W przypadku kontaktu z ciałem ogranicz czas bezpośredniego kontaktu.
8. Nie używaj produktu po jego zanurzeniu w wodzie.
9. Nieprawidłowa wymiana baterii może spowodować ryzyko wybuchu. Wymiana baterii może być przeprowadzona wyłącznie przez wykwalifikowany personel serwisowy. Nie zganiaj, nie przebijaj, nie rozbieraj ani nie wrzucaj baterii do ognia. Nie używaj produktu w przypadku znacznego

spuchnięcia baterii.

• Serwis i wsparcie posprzedażowe

1. Okres gwarancji rozpoczyna się od daty zakupu wskazanej na oficjalnym dowodzie zakupu (faktura lub ważny paragon). Jednostka główna (z wyłączeniem akcesoriów) podlega wymianie w ciągu 1 miesiąca oraz objęta jest 1-letnią gwarancją.
2. Zachowaj dowód zakupu i okaż go podczas zgłaszania reklamacji. W przypadku braku dowodu zakupu okres gwarancji będzie liczony od daty produkcji wskazanej na etykiecie produktu.
3. Jeśli podczas normalnego użytkowania w okresie gwarancyjnym wystąpi usterka wynikająca z wady produkcyjnej, produkt zostanie bezpłatnie naprawiony lub wymieniony po przeprowadzeniu kontroli.
4. Firma nie ponosi odpowiedzialności za jakiegokolwiek szkody pośrednie lub uboczne.
5. Gwarancja nie obejmuje:
 - a. Uszkodzeń spowodowanych niewłaściwym użytkowaniem lub czynnikami ludzkimi;
 - b. Uszkodzeń wynikających z nieprawidłowej instalacji lub nieprzestrzegania instrukcji obsługi;
 - c. Uszkodzeń spowodowanych klęskami żywiołowymi lub działaniem siły wyższej;
 - d. Uszkodzeń powstałych w wyniku nieautoryzowanej naprawy, modyfikacji lub demontażu;
 - e. Produktów po upływie okresu gwarancyjnego;
 - f. Akcesoriów produktu.